



BENS Towel Dispenser

USER MANUAL

Model: R-SR-TY-02S



BENS Hot and Cold Towel Dispenser!

To: MORI Towel Ltd

34 Bispham Road
Park Royal
LONDON
NW10 7HB
UK

(tel: 0208 133 3022)



MORI towel
Park Royal London NW10 7HB

www.moritrading.co.uk

[Read All Instructions Before Use]




[Product Overview]

Warning/Danger Read All Instructions Before First Use

- Do not place the the towel dispenser near a sink, or near water. If the the towel dispenser is submerged in water, risk of electric shock.
 - If the towel dispenser is submerged in water, turn off the towel dispenser from plug immediately, and do not touch the towel dispenser, risk of electric shock, seek professional help.
- Warning - To reduce the risk of burns, electric shock, fire or injury, take note of the following:
- Close supervision of the towel dispenser should be observed when dispensing towels
 - The towel dispenser must not be used by children.
 - Do not use any attachments not authorized by manufacturer/ distributor, as this may cause injury.
 - Use this product for its intended use, as described in this manual.
 - Do not use the towel dispenser if the cord or plug is damaged, the towel dispenser has been dropped, Call the manufacturer or Distributor for repair.
 - Never block the air vents of the the towel dispenser, check and clean air vents regularly, keep lint free.
 - Do not insert foreign objects into the towel dispenser or into the hose part of the dispenser, this may cause damage to the towel dispenser.
 - Ensure the towel dispenser is plugged into an earthed socket for safety. If unsure check with qualified electrician before use.

[SPECIFICATION]


Model: R-SR-TY-02S
Voltage: AC230V, 50Hz
Power :400w(Max)
Towel size: 24×25cm
Making speed: 25pcs/min
Weight: 12kg
Dispenser size:52x23x46.5cm



[Operating Instructions]


1. Fill water tank

Open the lid, take out water container and clean the inside of water tank with water, then fill up with water, and replace lid, and put the water tank upside down in the towel dispenser as shown.



2. Replacing Towel Roll

Place the towel core in the direction as illustrated. Lift the towel cover, smooth and flatten out towel, put the edge of towel in-line with the roller into the cover. Close lid.



3. Power

Ensure the normal/hot button is set to on before switching the towel dispenser on.

4. Pumping water into hydraulic spray system

Open front panel and press 'nozzle cleaning button'. Do not set to hot until water sprays out of nozzle pipe. Close the front panel once done.



5. Adjusting water flow

Press '1 Towel button' to check moistness of towel is as desired. If more or less moistness is wanted, open front panel and adjust the 'water flow knob' as shown.





Diagram shown with front panel open.

Caution: if water flow is set too low, may cause the towel to jam in the towel dispenser.

6. Towel Dispensing method



To set the desired number of towels in one cycle, press the 1 or 5 towel button continuously to get desired number of towels, e.g. if you need 10 towels, press '5 towels' button twice, if you need 6 towels, press '1 towel' button once, then '5 towel' button once immediately after, the display will then calculate and tell you how many towels have been requested.



[Warning!]

Do not open and attempt to repair the towel dispenser yourself, danger of electrical shock, may also cause the towel dispenser to malfunction and cause damage. Only authorised repairers should repair the towel dispenser. Repairing the towel dispenser yourself may invalidate the warranty.



In case of malfunction, unplug the towel dispenser at once.



If the towel dispenser is damaged then unplug at once, and seek advice before using again.



Please ensure the correct power source is used for the towel dispenser. Refer to the sticker on the side of the towel dispenser before plugging into mains.



Please ensure the instruction manual is read and understood before replacing towel roll and adding water to the water tank. For further information please contact distributor.



If the towel dispenser is left unused for long periods, drain water from the towel dispenser to prolong life of the dispenser.



If the towel dispenser is left unused for long periods, unplug the towel dispenser and store the cord away.



Please do not put foreign objects into the towel dispenser; this may cause damage, contact distributor for maintenance.



In case a foreign object is put in the towel dispenser accidentally, turn off the towel dispenser immediately, unplug from mains, and seek advice from authorized dealer for repair.

